Creative Muvo Slim

Audible User Guide.

Playing Audiobooks and Spoken Word content

1. Turning On the Player:
Press and hold the Play/Pause button for a few seconds.
The Creative logo will appear onscreen, followed by the MuVo Slim logo. Any audio files stored in your player will automatically start playing.

2. Turning Off the Player:
Press and hold the Play/Pause button for a few seconds until the Power Off message disappears.

3. Using the Scroller:
The Scroller is one of the most important features of your MuVo Slim. It is used to scroll through options and skip through tracks. Options can be selected by pressing down on the Scroller.

4. Audio playback:
In order to play music and Audible content, your MuVo Slim must be in Music mode. To enable Music mode, press and release the Scroller. When the Main Menu appears, Scroll Select the Music Mode icon.

5. Pausing a track:
Press the Play/Pause button.

6. Stopping a track:
Press the Play/Pause button to pause the track, and then turn the Scroller towards the right. The Stop icon will appear onscreen.

Skipping to the next or previous Audible audio program
Using the Scroller, press the Next Track/Fast Forward or Previous Track/Rewind button once.

7. Skipping through sections inside an Audible audio program:

1. While the audio is playing, press down on the Scroller. The LCD display will show a menu.
2. With the Skip Section logo highlighted, press down on the Scroller again.
3. This will take you to a menu where you can use the Next Track/Fast Forward or Previous Track/Rewind buttons on the Scroller to go directly to the beginning of other chapters.

8. Scanning through an audio track or Audible audio program
Press and hold down the Next Track/Fast Forward or Previous Track/Rewind button on the Scroller. The scan rate increases the longer you hold down either button.

10. Pausing Playback
Press the Play/Pause button to pause the audio. Press the Play/Pause button again to restart the audio.

11. Playback Position
If you stop or pause an Audible file, it will automatically bookmark that spot. The next time you play that file it will start from the bookmarked spot.

12. Volume control
To change the volume on your MuVo, simply press the Volume Increase or Volume Decrease button on the side of the device.